

Description

Cushions are used for their large absorbent capacity and are particularly used for placing under leaking machinery, pipework and taps. They can be used for large volumes of oil and water based fluid spills and are useful for protecting drains when a drain cover is not available.

Benefits & Features

- Large capacity in a compact sized cushion
- Leave under dripping taps and pipework
- Strong outer cover for durability
- Flexible enough to fit around obstructions
- Can be used to protect drains
- Use on oil and water based leaks

Directions for Use

Place cushion under leak and leave until saturated.

Technical Data

| | |
|------------------|--|
| Appearance: | Grey cushion |
| Material: | Spun bond polypropylene cover, melt blown polypropylene inner fill |
| Dimensions: | 50cm x 40cm x 4cm |
| Absorbency: | Approx 6.9 litres per pillow depending on product to be absorbed |
| Saturation Time: | Approx 60-120 minutes for 10W/40 engine oil |

Packaging

1 Pack = 10 Cushions



o e

is e ni a a a s ee is for genera g i an e r oses
on an a on ain infor a ion a is ina ro ria e for
er ain on i ions of se or ing a re o en a ions
an s gges ions are a e i o g aran ee r er
infor a ion is a ai a e fro o r e ni a e ar en